




ENG

Morgan folding wardrobe

UA

Розпашна шафа Морган

2100x1800x380 mm

**To avoid falling**


we recommend fixing the product to the wall using **corners** or **double-sided tape**

ENG

Щоб уникнути падіння виробу

рекомендуємо закріпити його до стіни кутиками чи двосторонню стрічкою.

UA



ENG



UA

RULES FOR USE AND CARE OF FURNITURE

1. Use furniture only in dry rooms protected from the effects of weather conditions.
2. Install with suitable tools according to these assembly instructions.
3. Try to assemble as close to the location as possible.
4. The body is assembling in a horizontal position.
5. Before moving furniture, make sure that it is not loaded with items.

Caution: moving furniture may damage it.

When moving, hold on to vertical elements only; moving furniture by horizontal parts can break the product.

6. Overloading the furniture can damage it.
7. From time to time check the fittings and their correct position.
8. Wipe the furniture surface only with a slightly damp cloth or paper towels. Do not use chemical cleaning agents other than those specifically made for this.





ПРАВИЛА ВИКОРИСТАННЯ ТА ДОГЛЯДУ ЗА МЕБЛЯМИ


1. Використовуйте меблі тільки в сухих приміщеннях, захищених від впливу погодних умов.
2. Виконуйте установку за допомогою відповідних інструментів відповідно до даної інструкції зі складання.
3. Намагайтеся проводити збірку якомога ближче до місця використання.
4. Збірка корпусу здійснюється в горизонтальному положенні.
5. Перед переміщенням меблів переконайтеся, що вони не навантажені.

Увага: переміщення меблів може привести до її пошкодження.

При переміщенні тримайтеся тільки за вертикальні елементи, переміщаючи меблі за горизонтальні деталі ви можете зламати виріб.



6. Перевантаження меблів може привести до їх пошкодження.
7. Час від часу перевіряйте кріплення і правильність їх положення.
8. Протирайте поверхню меблів тільки добре віджатою вологою тканиною або ж паперовими рушниками. Не використовуйте хімічні засоби для очищення, крім спеціально для цього призначених.








№	size / розмір	pack / уп.	qty / к-ть
1	2100 400	1/3	1
2	2100 400	1/3	1
3	2000 400	1/3	1
4	2000 400	1/3	1
5	2028 298	1/3	4
6	1766 400	2/3	2
7	578 400	2/3	1
8	578 400	2/3	1
9	578 380	2/3	1
10	578 380	2/3	4




№	size / розмір	pack / уп.	qty / к-ть
11	577 370	2/3	2
12	320 378	2/3	6
13	1766 66	2/3	2
14	598 338	2/3	6
15	350 170	3/3	3
16	350 170	3/3	3
17	529 334	3/3	3
18	529 160	3/3	3
19	572 326	3/3	3
20	986 572	3/3	3







2
x3





3
x3









4
x3






5





6











7











8







9



10



11



12

