










Instalation manual

STOL INES 8




Element symbol	Dimensions			Code	Package
1	805	908	1	STOL_160x210.001	1/2
2	805	908	1	STOL_160x210.002	1/2
3	500	908	1	STOL_160x210.003	1/2
4	1512	100	1	STOL_160x210.004	2/2
5	1512	100	1	STOL_160x210.005	2/2
6	729	120	1	STOL_160x210.006	1/2
7	729	120	2	STOL_160x210.007	1/2
8	729	120	1	STOL_160x210.008	1/2
9	729	120	2	STOL_160x210.009	1/2
10	729	120	1	STOL_160x210.010	1/2
11	729	120	1	STOL_160x210.011	1/2
12	780	100	2	STOL_160x210.012	2/2
13	780	100	2	STOL_160x210.013	2/2


6x pla stik f5 ⁴	6x pla stik f5 ³	1x GLUE y1	2x 750mm L-750	8x ø6x13 mm e3	16x 6 x13 mm e2
1x z1	8x k1	20x s2	20x ø15x12mm ø16 r16	20x ø8x30 mm f1	32x ø4x30 mm p21




1




2




3




4



5



7



6

